

Connecting a VAG factory rear-view camera version HIGH (with camera control unit - moving steering lines) or LOW to a device with NTSC-compatible composite input.

Required when factory head unit RNS315, RNS510, RCD510, Columbus, Bolero or Trinax is removed.

Fully plug and play.

